




Driveway Reminders

Avoid using jack stands or car ramps unless a piece of plywood is placed under them to help distribute the weight.



Excessive weight from large heavy vehicles can depress your new blacktop. Keep oil trucks, concrete trucks and any other heavy trucks off your new driveway. When storing campers, boats, 18-wheel trailers, and similar types of vehicles for long periods of time, place a piece of plywood under the tongue jack and also under the tires.


Lawn chairs, bicycle and motorcycle kickstands exert weight on concentrated areas and can create holes and depressions in your new driveway. Be cautious of possible heavy point loading during the warm months when your driveway is new.



Minnesota Asphalt
Pavement Association

www.asphaltisbest.com

Driveway Reminders



The edges are the weakest part of your driveway due to the lack of side support. Avoid driving on the edges since they may crack and cause indentation. We suggest building up the sides of your driveway with topsoil. This will support the driveway edges and enhance the appearance after grass is grown.

Avoid gasoline, oil, anti-freeze, power steering and transmission fluid spills and leaks. These will dilute the liquid asphalt in your blacktop.



Your driveway may appear different in some areas than in others because of the makeup of blacktop or placement conditions. Blacktop has various sizes of stone, sand, liquid asphalt, and other ingredients, which cause a varied texture of the surface. Also, blacktop areas that have been raked and spread in irregular areas with hand tools may appear different in texture from those spread by a conventional paving machine.



Minnesota Asphalt
Pavement Association

www.asphaltisbest.com